

PRODUCT RECORD CARD

THIS DOCUMENT SHOULD BE ISSUED WITH AND KEPT FOR EACH ITEM OR SYSTEM

- Please see the product label details required below.
- Consult the User Guide for advice on inspection, maintenance, lifespan etc. Other components within any fall arrest system in which products are used should conform to the relevant European standards (ENs) or in their absence other appropriate standards.

Product Label Definitions

1. Manufacturers contact details
2. Manufacturers product code
3. Date of manufacture
4. Read instructions supplied with product
5. Serial Number

2 Model: ABNAP
3 DOM: MM/YY
1 sales@abtechsafety.com
5 Serial No: XXXXXX
4 01244 837 050

All Products within this User Guide are manufactured within our BS EN 9001:2015 quality management system, under the supervision of:
 Satra Quality Assurance Ltd, Wyndham Way, Kettering, Northamptonshire NN16 8SD.
 Tel: +44 (0)1536 410 000 Fax: +44(0)1536 410 626

Abtech Safety Ltd, Units 1&2 Parkway Business Centre, Sixth Avenue,
 Deeside Industrial Estate, Flintshire, CH5 2LE
 Tel: +44(0)1244 837 050 Fax: +44(0)1244 837 051
 sales@abtechsafety.com www.abtechsafety.com

MANUFACTURE DETAILS

PRODUCT CODE	PRODUCT SERIAL NUMBER
FINAL INSPECTION PRIOR TO DESPATCH BY	DATE

RESCUE HARNESS (NAPPY)

TESTED TO BS EN 1497
 PRODUCT CODE: ABNAP

RESCUE HARNESS (NAPPY)

The Rescue Harness (Nappy) is for use by a trained and qualified rescuer only. It is suitable for raising and lowering both adults and children.

The positioning of the attachment point allows the user to maintain a near vertical position however if the user is unconscious an attendant rescuer should be raised or lowered with the casualty.

FITTING AND ADJUSTMENT

1. Slip one side attachment point around the casualty and bring to the front.
2. Slip the centre attachment point through the legs of the casualty from behind to the front.
3. Link the three attachment points together with a suitable karabiner.
4. Attach the karabiner to a rigging plate attached the rescuer or a rescue line.
5. Follow all best practice rescue techniques.



