

PRODUCT RECORD CARD

THIS DOCUMENT SHOULD BE ISSUED WITH AND KEPT FOR EACH ITEM OR SYSTEM

- Please see the product label details required below.
- Consult the User Guide for advice on inspection, maintenance, lifespan etc. Other components within any fall arrest system in which products are used should conform to the relevant European standards (ENs) or in their absence other appropriate standards.

Product Label Definitions

1. Manufacturers contact details
2. Manufacturers product code
3. Date of manufacture
4. Read instructions supplied with product
5. Identifying number of manufacture examination body
6. Serial Number
7. European standard that the product conforms to
8. UK Conformity Assessed mark

ABTECH SAFETY			
2 Model: SLIXWS	Serial No: XXXXXX 6	4	
3 DOM: MM/YYYY	BS EN EN795:2012 TYPE B	7	
CE 2777 5	sales@abtechsafety.com 1	UK CA 8	
	01244 837 050		

All PPE Products within this User Guide conform to the European Standards stated and are the subject of EU Certificates of Conformity issued by and under the supervision of the Notified Body:

SATRA Technology Europe Ltd (Ireland) Bracetown Business Park, Clonee, Co. Meath, D15 YN2P, Ireland (NB2777)
Tel: +353 1 437 2484

SATRA Technology Centre Ltd (AB0321) Wyndham Way, Telford Way, Kettering, Northamptonshire, NN16 8SD UK

Tel: +44 (0)1536 410 000 Fax: +44(0)1536 410 626

PPE Regulation (EU) 2016/425 as brought in UK Law and amended
Module B (Annex V) EU Type Examination and Module C (Annex VI)
Module D (Annex VIII)

Abtech Safety Ltd, Units 1&2 Parkway Business Centre, Sixth Avenue,
Deeside Industrial Estate, Flintshire, CH5 2LE
Tel: +44(0)1244 837 050
sales@abtechsafety.com www.abtechsafety.com

MANUFACTURE DETAILS

PRODUCT CODE	PRODUCT SERIAL NUMBER
FINAL INSPECTION PRIOR TO DESPATCH BY	DATE

WIRE STRETCHER ANCHOR STROPS

CONFORMS TO BS EN 795:2012
PRODUCT CODE: SLIXWS



1. Connect the karabiners to the attachment points on the stretcher, ensuring the gates are locked closed.

Connect the coloured strop to the corresponding coloured stretcher eye for a slightly 'head up' position.

Connect the coloured strop to the opposite coloured stretcher eye for a slightly 'head down' position.

2. Attach the top connector to an approved anchor for lifting.

For vertical lifting, attach the coloured strops to the corresponding coloured stretcher eyes, ensuring all 4 strops are connected.

Green: 43cm
Blue: 50cm

